




FasTop™ M Urethane Mortar System

General Polymers **FasTop M** URETHANE MORTAR SYSTEM is a low odor, troweled applied mortar installed at 1/4" - 3/8" thickness. Under normal conditions, **FasTop M** is hand troweled onto the substrate without the use of a primer or topcoat. **FasTop M** is designed for conditions requiring rapid installation and protection of the concrete, wood or steel substrate from thermal shock, impact, corrosion, mild chemical attack and abrasion. **FasTop M** is textured and provides some skid inhibition under most wet process conditions, and will remain so throughout the life of the floor. **FasTop M** can be used on new concrete, or to restore rough or badly damaged floor surfaces that have been exposed to years of contamination. **FasTop M** is extremely durable, and in most cases, has physical characteristics which are approximately double that of concrete.



Advantages

- Minimal downtime, quick turnaround
- Bonds to slightly damp substrate
- Thermal shock resistant
- No moisture vapor emission testing required
- Unaffected by freeze/thaw cycles
- Wide service temperature range (-50°F to 235°F)
- Optional primer and topcoat
- Impact resistant
- Low to no odor, water-based
- Interior or exterior use
- Accepted for use in USDA inspected facilities
- Chemical resistant to:

28 Day Exposure @ 72°F	Result
Alcohol	NE
Ethylene Glycol	NE
Fats, Oils & Sugars	NE
Gasoline, Diesel & Kerosine	NE
Hydrochloric Acid (<35%)	NE
Lactic Acid (Milk)	NE
Mineral Oils	NE
Most Organic Solvents	NE
Muriatic Acid	NE
Nitric Acid (<10%)	NE
Nitric Acid (<30%)	Slight Softening
PM Acetate	NE
Phosphoric Acid (<50%)	NE
Potassium Hydroxide (<50%)	NE
Sodium Hydroxide (<50%)	NE
Sulfuric Acid (<50%)	Slight Gloss Loss
Water	NE
Xylene	NE

Uses

- Cagewash areas, chemical processing plants
- Commercial kitchens, dairy plants
- Meat and poultry plants, pulp and paper plants
- Restrooms and concession stands
- Sugar processing plants, walk-in coolers
- Walk-thru autoclaves, wastewater treatment facilities

Typical Physical Properties

Color	Red and Dark Gray
Working Life, mixed @ 77°F	20 minutes
Cure Time @ 77°F	
Recoat	4-5 hours
Foot Traffic	4-6 hours
Full Service	10-12 hours
Tensile Strength	550-600 psi
ASTM C 307	
Compressive Strength	6,000 psi
ASTM C 579	
Flexural Strength	1,950 psi
ASTM C 580	
Coefficient of Thermal Expansion ASTM C 531	1.1 x 10 ⁻⁵ in/in/° F
Vicat Softening Point	266° F
Density	130 lbs/ft ³
ASTM C 905	
Impact Resistance	No damage @
ASTM D 2794	16 ft. pound
Abrasion Resistance	70 mgs lost
ASTM D 4060 CS-17 Wheel, 1,000 cycles	
Service Temperature @ 3/8" Application	-50°F - 300°F

Limitations

For substrates on or below grade, an effective moisture vapor barrier is required.

The substrate must be structurally sound, cleaned of any foreign matter that will inhibit adhesion.

Do not apply in temperatures below 40° F or above 85° F or when relative humidity is greater than 85%. Do not apply to non-reinforced sand cement screeds, asphaltic or bitumen substrate, glazed tile or nonporous brick, tile, or magnesite, copper, aluminum, soft wood, existing coatings of epoxy, polyester, or urethane composition, elastomeric membranes, fiber reinforced polyester (FRP) composites. Do not apply to wet concrete or to polymer modified patches with a moisture content greater than 10%. Do not apply to concrete if temperature is within 5° F of dew point.

Protect substrate during application from condensation from any overhead leaks. Do not apply to overhead surfaces.

Do not featheredge.
Do not hand mix.
Do not apply to cracked or unsound substrates.

Full chemical resistance is achieved after a seven (7) day cure. Consult the Technical Service Department for specific chemical resistance.

Installation

The following information is to be used as a guideline for the installation of the **FasTop M** URETHANE MORTAR SYSTEM. Contact the Technical Service Department for assistance prior to application.

Surface Preparation

General Polymers **FasTop M** URETHANE MORTAR SYSTEM is normally applied to concrete, but may be successfully applied to mild steel and wood block. Surface contaminants and/or weak spots must be removed and a clean, hard surface exposed to ensure proper bonding to the substrate.

Concrete surfaces shall be abrasive blasted to remove all surface contaminants and laitance. The prepared concrete shall have a surface profile equal to CSP 4-6. Refer to Form G-1. Consult the Technical Service Department if oil or grease is present.

After initial preparation, inspect the concrete for bug holes, voids, fins and other imperfections. Protrusions shall be ground smooth while voids shall be filled with a General Polymers system filler. For recommendations, consult the Technical Service Department.

New concrete should be cured a minimum of 28 days. Use a light steel trowel finish. Moisture content of the concrete should not exceed 10%.

Application Information

Material	Mix Ratio A:B	Theoretical Coverage Per Coat	Packaging
Cove Base			
4040	2:1	300 sq. ft. / gal	3 or 15 gals
4060	1 unit	15-20 lin. ft.at 6" cove 1"radius	Short Filled Gallon
5055			30 lbs
Mortar			
Optional Primer:			
4040	2:1	300 sq. ft. / gal	3 or 15 gals
4070	1 unit	17-18 sq. ft. / gal @ 1/4" 11-12 sq. ft. / gal @ 3/8"	Short Filled Gallon Containers
5075		42 lbs / 1 unit	42 lbs

Service Temperature

Throughout the application process, substrate temperature should be 40°F - 85°F. Substrate temperature must be at least 5°F above the dew point. Applications on concrete substrates should occur while temperature is falling to lessen offgassing. The material should not be applied in direct sunlight, if possible.

Extreme Conditions

Ideal conditions for mixing and laying the **FasTop M URETHANE MORTAR SYSTEM** is between 40° F and 85° F. Do not apply when temperatures are below freezing. **FasTop M** has a very short pot life above 80° F.

Cold Temperatures Below 50° F

Keep materials stored and mix in 60° F to 70° F conditions. Protect application area with cover or tent. Flame heat concrete immediately ahead of layers. Use hot air blowers to raise temperature under cover or tent. Maintain air temperatures for at least 4-6 hours after laying. Allow a longer time period for the **FasTop M** to reach an operating strength (24-48 hours depending upon substrate and ambient air temperatures).

Hot Temperatures Above 80° F

Keep materials stored and mix them in an air-conditioned environment of 60° F - 70° F. Do not lay the **FasTop M** in direct sunlight. Shade with a tarpaulin or similar material. Work early and/or late, and preferably at night if daytime temperatures are extreme.

Edge Terminations

All free edges of the **FasTop M**, whether at the perimeter, along gutters or at drains, will require extra anchorage to distribute mechanical and thermal stresses. This is best achieved by forming or cutting grooves in the concrete. Grooves should have a depth and width of two times the thickness of the **FasTop M**. If necessary, protect all free edges with mechanically attached metal strips. NEVER featheredge, always turn into an anchor groove.

Expansion Joints

Expansion joints should be provided in the substrates at the intersection of dissimilar materials. Isolate areas subject to thermal stresses, vibrational movements or around load-bearing columns and at vessel sealing rings. All cracks should be routed out and filled with **FasTop M** prior to floor application. Large cracks may require treatment as expansion joints with an elastomeric sealant.

Cove Base

Cove base should be installed prior to the floor. Tape out cove with duct tape or a good quality masking tape. Terrazzo strips will also work.

Priming: Prime wall with 4040 FasTop Urethane Primer. Primer only has a 10 minute pot life. Be sure to prime entire surface and about halfway onto tape. Prime only what cove base that can be installed within 30 minutes. Begin installing cove base right away – No need to wait for primer to tack up.

Mixing: Do not mix partial units, the fine aggregate and pigment can and will separate. A drill and a paddle work the best, but a KOL mixer works well also. Mix pre-measured unit of 4060A for one minute, add 4060B pre-measured unit and mix. Slowly add 5055 aggregate and mix until thoroughly wet out. Immediately pour mixed material out of bucket, in a bead, next to the wall. Rough apply cove mortar using a trowel. Do not worry about trowel marks at this time; just get all the mixed material applied to the wall at about 1/8" thick. Material will need to be finished within approximately 20 minutes depending on temperature. Placing a halogen light next to cove base will cast shadows and assist on finishing the cove base with minimal waves and/or trowel marks. Use a minimum of a 3/4" radius cove trowel and finish cove base. Any smaller may result in a loss of the radius once the floor is tied in. Lightly misting cove trowel with water, as a trowel lube, works well - **Do not use isopropyl alcohol**. Carefully remove tape and finish rough edges. Install floor once cove is hard to the touch, about 2 1/2 to 3 hours.

Required Tools: Drill, proper mixing paddle, 3" x 8" trowel works best to apply, margin trowel, and a radius cove trowel – Minimum of 3/4" but 1" is preferred.

Primer (Optional)

Mixing and Application

1. Add 2 parts 4040A (resin) to 1 part 4040B (hardener) by volume. Mix with low speed drill and Jiffy mixer until uniform. To insure proper system cure and performance, strictly follow mix ratio recommendations.

2. 4040 may be applied via spray, roller or brush. Apply 4-5 mils, evenly, with no puddles. Coverage will vary depending upon porosity of the substrate and surface texture.

3. Wait until primer is tacky (minimum 15 minutes), before applying the **FasTop M System**. If primer is not going to be topped within open time, broadcast silica sand into resin lightly but uniformly.

Mortar

Mixing and Application

1. Set up mixing station as near to work areas as possible. Exothermic heat will be generated and flash setting may occur if the material remains in mixer or a heap on the floor for longer than ten minutes. Multiple batches may be mixed in a mortar mixer. DO NOT mix more material than can be applied in 15 minutes.

2. Add 4070A (resin) to 4070B (hardener). Mix with low speed drill and Jiffy mixer for one minute and until uniform. The white (A) and brown (B) colors should blend to a uniform caramel color.

3. Slowly pour 42 lbs. of 5075 aggregate (one bag) to mixed material until aggregate is thoroughly 'wet-out'. Do not mix for more than 3 minutes. Immediately pour the mixed material onto substrate to 5/16" to achieve a total thickness of desired floor of 1/4". Apply at 1/2" to achieve a finished thickness of 3/8". DO NOT allow the mix to sit in the mixer or in a pile on the floor.

4. Allow a wet edge of between 8-10 linear feet per installer. Divide up work area accordingly.

5. DO NOT use a power trowel, power float, serrated hand trowel or screed box. Compact and smooth the mixed material using a normal steel plastering or cement finishing trowel.

6. Using considerable pressure on the trowel, spread the material from side to side, push back into previous mix (wet edge), pull forward to establish the thickness and then, with a light pressure, trowel from side to side to close up. The last few strokes should always be in one direction only, left to right or right to left. NEVER back and forth. Excess troweling will bring resin to the surface and may cause a smooth spot.

8. Allow to cure for 4-6 hours (77°F) prior to foot traffic.

Cleanup

Clean up mixing and application equipment immediately after use. Use toluene or xylene. Observe all fire and health precautions when handling or storing solvents.

Safety

Refer to the MSDS sheet before use. All applicable federal, state, local and particular plant safety guidelines must be followed during the handling and installation and cure of these materials.

Safe and proper disposal of excess materials shall be done in accordance with applicable federal, state, and local codes.

Material Storage

Store materials in a temperature controlled environment (50°F - 90°F) and out of direct sunlight.

Keep resins, hardeners, and solvents separated from each other and away from sources of ignition. One year shelf life is expected for products stored between 50°F - 90°F.

Maintenance

Occasional inspection of the installed material and spot repair can prolong system life. For specific information, contact the Technical Service Department.

Shipping

- Destinations East of the Rocky Mountains are shipped F.O.B. Cincinnati, Ohio.
- Destinations West of the Rocky Mountains are shipped F.O.B. Victorville, California.

For specific information relating to international shipments, contact your local sales representative.

Disclaimer

The information and recommendations set forth in this document are based upon tests conducted by or on behalf of The Sherwin-Williams Company. Such information and recommendations set forth herein are subject to change and pertain to the product(s) offered at the time of publication. Published technical data and instructions are subject to change without notice.

Consult www.generalpolymers.com to obtain the most recent Product Data information and Application instructions.

Warranty

The Sherwin-Williams Company warrants our products to be free of manufacturing defects in accord with applicable Sherwin-Williams quality control procedures. Liability for products proven defective, if any, is limited to replacement of the defective product or the refund of the purchase price paid for the defective product as determined by Sherwin-Williams, NO OTHER WARRANTY OR GUARANTEE OF ANY KIND IS MADE BY SHERWIN-WILLIAMS, EXPRESSED OR IMPLIED, STATUTORY, BY OPERATION OF LAW OR OTHERWISE, INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.



**SHERWIN
WILLIAMS**

WEBSITE: www.generalpolymers.com © The Sherwin-Williams Company, All Rights Reserved September 2008 Cincinnati, OH 800-543-7694